FITTING INSTRUCTION



This document is intended as an instruction to repair or modify a product. Any work should be carried out by a competent individual, adhering to health and safety guidelines and wearing the correct PPE.

Title:

Worktop Extension Flap Retrofit Instruction

Document Ref:	STD-FI-2025-0001	Initial Release Date :	02/01/2025
Ranges Affected :	PX1, PXR, PX2, PS6, PSR, PG2 & DYR	Models Affected :	All

Please follow the steps below to fit a kitchen worktop extension flap on relevant models. NOTE: not all models in the ranges can have this fitted - details on the last page.

Parts:



2x Spring Hinged Bracket



4x Self Tapping Screw 10x1/2



4x Wood Screw 5x5/8



1x Extension Flap (Model Specific)

Tooling:



Screwdriver & PZ2 bit



Tape Measure

Step

Operation Description:

Photo:

Fix the 2x spring hinge brackets to the underside of the worktop using 4x 5x5/8 screws provided.

Ensure the hinges are oriented with the upright part of the hinge at the rear of the worktop (which is the flat edge of the

hinge at the rear of the worktop (which is the flat edge of the worktop)



Op.	Operation Description :	Photo :
2	There are 4x pilot holes in the worktop which correspond to the holes on the hinges as shown here.	Framework and the state of the
3	Once the hinges fitted to the worktop, the assembly should look like this (viewed upside down)	
4	Turn the assembly over, align the extension worktop level with the main kitchen worktop and fix the assembly to the side of the kitchen unit using 4x 10x1/2 screws. NOTE: it may be necessary to have one person hold the assembly inplace whilst another fixes the screws. Most models have a hollow panel with timber frame structure. There are designated timber supports built in to allow fitmant of this extension flap. NOTE: Check the diagrams on the last page for help locating the support timbers.	
5	Installation is now complete. The worktop can be folded down when not in use as per this photo.	

Op.	Operation Description :	Photo :
EX	The L/H kitchen panel has support timber built in specifically to fit this extension flap. See table below for model specific dimensions. To find the supports measure the dimensions from the front edge (green line). Measure XXX (from the green line to the red line) for the R/H bracket. Measure XXX (from the green line to the blue line) for the L/H bracket. These are the measurements to the centre of each support but 5mm in either direction will still find the supports. NOTE: SOLID indicates the panel is solid wood so the hinges can be screwed in any position on the panel. NOTE: N/A indicates the kit cannot be fitted to that model.	

	Range	Models	Distance Between	RED	BLUE
			Hinges		
PX1	Phoenix	420	N/A	N/A	N/A
PX1	Phoenix	440, 640, 642, 644, 760	320mm	60mm	350mm
PXR	Phoenix+	420	N/A	N/A	N/A
PXR	Phoenix+	440, 640, 642, 644, 650	320mm	60mm	350mm
PS6	Pegasus Grande	Bologna, Brindisi, Messina, Rimini	320mm	60mm	350mm
PS6	Pegasus Grande	Palermo, Turin	N/A	N/A	N/A
PSR	Pegasus Grande SE	Ancona, Palermo, Turin	N/A	N/A	N/A
PSR	Pegasus Grande SE	Bologna, Brindisi, Messina, Rimini	320mm	60mm	350mm
DYR	Discovery+	D4-2	180mm	80mm	260mm
DYR	Discovery +	D4-4	180mm	80mm	260mm
PX2	Phoenix GT75	420	N/A	N/A	N/A
PX2	Phoenix GT75	440, 640, 642, 644, 762	290mm	60mm	350mm
PG2	Pegasus Grande GT75	Amalfi, Bologna, Brindisi, Messina, Rimini	290mm	SOLID	SOLID
PG2	Pegasus Grande GT75	Ancona	290mm	SOLID	SOLID