

Russell Hobbs Microwave Modification - Instructions for Fitting to Base

Microwave and Base Modification Instructions

Tools needed:

- Jack-nut reactor tool (e.g. Sealey AK 393)
- Stanley knife
- Phillips No2 screwdriver
- Flat bladed screwdriver or trim lever

Parts list (Included in Microwave Kits 2990602 and 2990596 ONLY)

Fittings

1430018	M4 Short Jack-nut Series - SN4	4 off
1400081	M4 Form A Washer A2 Stainless Steel	4 off
1093068	M4 x 35 Pan Head Screw BZP	4 off
1400031	3.5mmx30 Csk Pozi Stl Screw	4 off
6151448	Bailey Grau Self Adhesive Screw Cover 19mm	4 off

Microwave Base (model-specific)

1520981	Adamo Optional Microwave Base	1 off
6197785	Adamo 75-4DL Optional Microwave Base	1 off

Additional Components for full assembly

6234621	Russell Hobbs RHFM2002B Microwave	1 off
6203552	Adamo Kitchen Locker Microwave Surround	1 off

Microwave and Base Modification Instructions

1. Remove the microwave's feet. A small flat blade screwdriver under the foot to lever it up is ideal.



2. Remove the rivet pin from the foot:



3. Carefully cut the barbs off flush with the top of each foot.



4. Screw Jack-nut onto the reactor tool and place into plain hole in base of Microwave, fully react and unscrew mandrill to release reactor tool.



5. Assemble plywood base to the microwave. Rebated holes to underside, plain side upwards. Add a washer under each screw and attach base through the feet, screwing into the Jack-nut.



6. Microwave and base can now be fitted into cupboard space with fascia.

