

PRODUCT GUIDANCE



This document is intended to provide guidance on fitting or operating a product. Any work should be carried out by a competent individual, adhering to health and safety guidelines and wearing the correct PPE.

ADD SKIRT CHANNEL OPENING TO SKIRT RAIL

This a guide on how to add a skirt opening to the channel of an awning skirt rail. We often supply a longer length of skirt to aid stock control and reduce the parts count.

Models affected: all Caravans

STEP ONE:

Cut the skirt rail to the required length.

This may leave one or both ends with no opening for the skirt channel.

STEP TWO:

Measure 95mm from the end of the skirt and mark with a chinagraph pencil or masking tape.



STEP THREE:

Using a palm router and ¼" Trimmer Router bit (as below) trim away the plastic from the end of the skirt either side of the existing channel.

